

# Personal Alarm With LED Light



## Safety Alarm for use by:

- Joggers
- Elderly
- Disabled
- Night shift workers
- People who live alone
- Students

## MC-383 INSTRUCTIONS

### WARNING:

The alarm sound is very loud ---  
never put the unit close to your ears!

### To Change Batteries:

Remove two screws from  
the back cover and replace  
Two (2) - AAA batteries.



### Alarm Mode:

Pull hand strap away from  
the alarm body to release  
the arming pin. Alarm will  
sound and light will flash.

To silence the alarm, insert the  
pin back into socket on alarm  
body.

### LED Light:

Press and hold the side  
panel light button to  
activate the flashlight.

**Note:** Will not sound alarm.

### Warn / Test Button:

Press button on alarm face  
to activate alarm sound for  
3 seconds.

**Note:** Alarm will stop  
automatically.

