

Personal Alarm With LED Light



Safety Alarm for use by:

- Joggers
- Elderly
- Disabled
- Night shift workers
- People who live alone
- Students

MC-383 INSTRUCTIONS

WARNING:

The alarm sound is very loud ---
never put the unit close to your ears!

To Change Batteries:

Remove two screws from
the back cover and replace
Two (2) - AAA batteries.



Alarm Mode:

Pull hand strap away from
the alarm body to release
the arming pin. Alarm will
sound and light will flash.

To silence the alarm, insert
the pin back into socket on
alarm body.

LED Light:

Press and hold the side
panel light button to
activate the flashlight.

Note: Will not sound alarm.

Warn / Test Button:

Press button on alarm face
to activate alarm sound for
3 seconds.

Note: Alarm will stop
automatically.

